


Manual Water Dispenser



Assembly

1. Prior to assembly, wash all tubes with soapy water and rinse thoroughly. Rinse all other parts thoroughly with warm water as well.
2. Begin by connecting the main tube (A) and second tube (B) together
3. Insert the connected tubes into the bottom of the dispenser unit (D) and twist clockwise, applying pressure until secure. (If experiencing difficulty you may place the head of the tube in boiling water for 10-20 seconds in-order to soften the tip.)
4. Attach the spout (E) to the front of the dispenser unit with a slight twist to secure, and ensure the spout opening is pointed downward.
5. After removing the bottle cap, insert assembled pump into the water bottle. Turning connector ring (F) clockwise until it is tightly secure.
6. Press dispenser button (G) down firmly to dispense water and repeat.

Use

1. Place cup, glass or pitcher under spout
2. Press down on top of pump several times to make water flow.

Cleaning and Care

1. Clean pump with a cloth, mild dishwashing soap and water
2. Clean tubes and spout in dishwasher
3. Store in a clean, dry location
4. For your convenience, a handy brush (H) is included.